

SANFOOT

NATURAL WOOD VENEER WALLCOVERING

INSTALLATION CLEANING

The cleaning procedure is an important part of the installation process of SanFoot's overall appearance. We recommend cleaning the surface with clean water by using a lint-free cloth or a good grade sponge during installation. Wipe the surface 1-2 times throughout the final SanFoot installation process and replace the water as required.

Adhesive and paste residue not properly cleaned off the wood surface can cause a cloudy or milky white appearance after a 30-60-day period following the installation. If this occurs, it is recommended to use an adhesive cleaning chemical by Zinsser Co. called DIFF. DIFF can be purchased at almost all paint supply stores.

ANNUAL MAINTENANCE

SanFoot with Standard Finish

SanFoot is easy to maintain and only requires an annual surface cleaning by choosing one of two methods.

- Murphy's Oil Soap
Follow the manufacturer's direction to clean the entire surface of all exposed wood.
- Warm Water
Using a damp lint-free rag or sponge, clean the wood surface with warm water.

SanFoot with Elite Finish

Follow the same maintenance instructions as Standard Finish.

Notes

1. Do not use any abrasive cleaners or pads on any SanFoot surface.
2. Do not clean SanFoot more than once a year.

July 2022