



HANGING INSTRUCTIONS FOR UN-PASTED WALL LINER

This product is recommended as a base for new wallcoverings or paint to be applied to problem walls. It will cover cracks, rough spots, cement blocks and paneling. It is not intended for bridging gaps with a width or depth of ¼ inch or more. Gaps and cracks of ¼ inch or more should be filled prior to installation. Although general recommendations are given in these instructions, the wide range of applications, types of surfaces, textures, treatments, and other conditions beyond our control dictate that appropriate wall preparation products and adhesives will need to be selected to match each individual installation. A test installation is strongly advised.

1. Surface to be covered must be dry and structurally intact. Remove all loose paint and old wallcoverings. (If mildew is present, remove and treat to inhibit future growth.) Sand protrusions and seal the surface with a primer that is appropriate with the wall surface.
2. Use lead pencil to mark walls and back of wall liner. Do not install unless temperature is above 55 degrees f.
3. This wall liner product should be hung horizontally with the natural “curl” of the material toward the wall. Measure the length and cut strips allowing 3-inches for trimming at both ends.
4. Brush or roll undiluted heavy-duty, pre-mixed vinyl adhesive on the back of the wall liner, making sure the paste is applied all the way to the edges. To carry the pasted strip to the wall, fold wet side to wet side. Do not crease.
5. Apply bottom strip first, with overlap onto baseboard. Smooth strips to the wall with a smoothing brush. Remove all air pockets. Butt all seams – do not overlap seams.
6. Use scissors, single edge razor, or knife to trim excess at baseboard, ceiling line, around windows and doors, etc.
7. Allow a minimum of 24 hours for wall liner to dry. (Room conditions will determine actual drying time.) It is critical that the wall liner and underlying paste are completely dry before proceeding. Apply a water-based acrylic, or other manufacturers recommended primer/sealer to the wall liner. When dry, apply final wallcovering per manufacturer’s instructions.
8. If wall liner is to be painted, apply two coats of high quality latex paint after using appropriate primer for best results.