

level

Care & Cleaning Guide: Targa Rigid Wall Protection Panels

Basic Cleaning

Light soil, crayon, pencil, lipstick, blood, and other mild staining agents can usually be removed by using a soft cloth with mild soap and water.

Additional household cleaners could be used such as Green Works® All-Purpose Cleaner, Seventh Generation™ Multi-Surface Cleaner, and Mrs. Meyer's® All-Purpose Cleaner or an equivalent product. A Mr. Clean® Magic Eraser™ can be used in concert with any of these cleaners.

Always scrub with the grain of the Targa®. The cleaned surface should always be “rinse wiped” with clean water and dried to remove any remaining residue.

Stubborn Stains

Stubborn stains, ball point pen, permanent marker, dry erase marker, paint and shoe scuffs can usually be removed by using a Mr. Clean® Magic Eraser™ in concert with a product like Spartan Graffiti Remover SAC®.

Again, always scrub with the grain and “rinse wipe” with clean water and dried to remove any remaining residue.

Do Not Use

DO NOT USE methyl ethyl ketone (MEK), cleaners containing MEK, bleach, or any other cleaners containing harsh solvents on any Targa® product.

Powdered cleansers **ARE NOT RECOMMENDED** as they are abrasive and tend to leave a troubling residue if not utilized properly.

DO NOT USE Scotch-Brite®, Brillo®, S.O.S.® pads, or steel wool on any Targa® product.
